



INSTRUCTION MANUAL FOR BRUDER "HAMPTON" AUTOMATIC BI-DIRECTIONAL AUTO & SELF-WIND MOVEMENT: SEAGULL AUTOMATIC

- A) DISPLAY AND BUTTONS
- B) WINDING THE SPRING
- C) SETTING THE TIME

A) DISPLAY AND BUTTONS



B) WINDING THE SPRING

1. Ensure the Crown is in the normal position.
2. Wind the Crown in a clockwise direction until the Spring is coiled tightly.

C) SETTING THE TIME

1. Pull the Crown out to the 1st position.
2. Turn the crown clockwise to set the time.
3. After the time has been set, push the crown back to the normal position.

#WELCOME TO THE BRUDERHOOD